



СПИСОК УЗЛОВ ДЛЯ SUZUKI T500 123

//WWW.OEM.MOTO-ALL.RU/


ТЕЛ.: +7 (495) 177-12-75




Карбюратор




Сцепление




Картер двигателя




Крышки картера



Коленвал




Головка блока цилиндров и фильтр




Электрические компоненты

FIG. 19 FRAME - OIL TANK




Frame - oil tank

FIG. 25 FRONT FORK




Front fork

FIG. 26 FRONT WHEEL




Front wheel

FIG. 27 FUEL TANK




Fuel tank

FIG. 10 GEAR SHIFTING




Gear shifting

FIG. 12 GENERATOR - IGNITION COIL




Generator - ignition coil

FIG. 28 HANDLE BAR - CONTROL CABLE




Handle bar - control cable

FIG. 27 HANDLE SWITCH




Handle switch

FIG. 15 HEADLAMP




Headlamp

FIG. 11 KICK STARTER




Kick starter

FIG. 6 MUFFLER




Muffler

FIG. 7 OIL PUMP




Oil pump

FIG. 31 OPTIONAL




Optional

FIG. 17 REAR COMBINATION LAMP




Rear combination lamp

FIG. 28 REAR SWINGING ARM




Rear swinging arm

FIG. 30 REAR WHEEL




Rear wheel

FIG. 32 SEAT - FENDER




Seat - fender

FIG. 14 SPEEDOMETER - TACHOMETER




Speedometer - tachometer

FIG. 20 STAND - FOOTREST BAR




Stand - footrest bar

FIG. 9 TRANSMISSION



Transmission

FIG. 16 TURN SIGNAL LAMP



Turn signal lamp