




05402 F.3



800-875-8752







FIGURE 13




page 63




Цилиндр




Электрические компоненты




Frame




Frame cover (ds80t)




Frame cover (ds80x)




Front fork




Front wheel




Fuel cock




Fuel tank




Gear shifting




Handlebar - control cable




Headlamp



Headlamp housing - front fender




Kick starter




Left handle switch

FIG. 13




Magneto

FIG. 7




Muffler

FIG. 8




Oil pump

FIG. 31




Oil tank

FIG. 33




Optional

FIG. 18



Prop stand - brake pedal


FIG. 31



Rear fender

FIG. 31


FIG. 30



Rear swinging arm

FIG. 32


FIG. 32



Rear wheel

FIG. 28


FIG. 28



Right handle switch

FIG. 15


FIG. 15



Tail lamp

FIG. 10

FIG. 10



Transmission

FIG. 12

FIG. 12